RauHeat Pipe Series Template Instructions

2021-10-27

MagiCAD

Taking the template into use

1. Download the .zip file to your computer. Unzip the file to a suitable location.

2. Start MagiCAD, open the project management window, and choose *Pipe series* from the left part of the window.

3. Click the right button of your mouse and choose *Manager.*



© Copyright 2021 MagiCAD Group

4. Change the source project file to RAUHEAT.EPJ.



5. Choose needed pipe series (or all) and add it to your project file.

© Copyright 2021 MagiCAD Group



6. New RAUHEAT pipe series are added to the current project file and can be used in the drawing.



© Copyright 2021 MagiCAD Group



© Copyright 2021 MagiCAD Group