
User's Guide



RauHeat Template Instructions

Document revision 2013-03-15

MagiCAD® Copyright © 1998-2013 Progman Oy. All rights reserved.

MagiCAD is a registered trademark of Progman Oy.

AutoCAD is a registered trademark of Autodesk Inc.

Windows is a registered trademark of Microsoft Corporation.


All other product names are trademarks of their respective holders.

PROGMAN OY
www.progman.fi


RauHeat template

Taking the template into use


1. Download the .zip file to your computer. Unzip the file to a suitable location.
2. Start MagiCAD, open the project management window, and choose *Pipe series* from the left part of the window.
3. Click the right button of your mouse and choose *Manager*.




4. Change the source project file to RAUHEAT.EPJ.



5. Choose needed pipe series (or all) and add it to your project file.



6. New RAUHEAT pipe series are added to the current project file and can be used in the drawing.



Mc MagiCAD HPV - Heating Pipe Options

Supply Water

Series:

Size: Fusio Fusiotherm PN10 /Retherm
INOX Viega Sanpress INOX
Mapress Mannesmann Mapress
PEX Plastic pipe PEX
PexFlex - PexFlex 1-pipeset/heating
Prestabo Viega Prestabo

Insulation:

s [mm]:

User field1 of series:

Synchronize ☒

Return Water

Series:

Size: Locked: ☐

Insulation:

s [mm]:

User field1 of series:

Status

Status:

Radius for flexible pipes

☒ Do not use ☐ Use

Alignment

☐ ☐ ☐ Horizontal extra offset

☐ ☒ ☐

☐ ☐ ☐

Routing

☒ Smart ☐ Direct

Pipe Positioning After Vertical

Pipe positioning from cursor pipe

Top ☐
Left ☐ Right ☒
Bottom ☐

Distance [mm]:

Height Difference

☒ 90 ☐ 45

dH in branch [mm]:

Ok Cancel