

Repus MagiCAD Cloud Plugin for AutoCAD

10/09/2026

Content

1	ABOUT THIS DOCUMENT	3
1.1	Installing the software.....	3
1.1.1	Required third-party software	3
1.1.2	Installation	3
2	STARTING THE PROGRAM	4
3	HOW TO USE THE PLUGIN	6
3.1	Nozzle duct.....	6
3.2	Displacement diffuser	9

1 About this document

This document contains instructions on using plugin *Repus MagiCAD Plugin*.
Repus MagiCAD Plugin is a Web-based extension to MagiCAD software.

1.1 Installing the software

1.1.1 Required third-party software

64-bit Repus MagiCAD Plugin works with the following MagiCAD versions

- MagiCAD for AutoCAD 2026 and AutoCAD 2023-2026
- MagiCAD for AutoCAD 2027 and AutoCAD 2023-2027

1.1.2 Installation

1. The installation package is available at MagiCAD's website

<https://portal.magicad.com/download/ProductSearch?searchStr=repus&categoryId=3>


2. Run the Repus MagiCAD plug-in installer on your workstation

Administrator privileges are recommended for installation. **Note if you have several AutoCAD versions on your workstation:** Before you run the installation program, start MagiCAD to make sure that *Repus MagiCAD Plugin* installs on the same AutoCAD platform as MagiCAD.


2 Starting the program

Before you start using *Repus MagiCAD Plugin*, start MagiCAD and open a Ventilation and Piping project.

The uninstallation of the older plugin versions (2026.6.1 or older) does not remove the customization file (CUIX) from AutoCAD. Run the CUILOAD (or MENULOAD) in AutoCAD, and unload the Repus menu customization file from the AutoCAD (if present). Plugin will create the ribbon panel and button programmatically so separate customization file is not needed.



Locate the MagiCAD Connect tab from the AutoCAD ribbon. Once the Repus MagiCAD plugin is loaded, the ribbon panel for the plugin can be found from the MagiCAD Connect tab. When the drop-down button is clicked, the list of available operations will be shown.




Information for network administrators:

Plugin requires connection to Repus web site. Internet Explorer control is used to browse web pages from http://www.repus.se/repus/index.php?command=open_nozzle_duct_from_magicad. Standard HTTP GET (TCP, default port 80 should be used) method is used to retrieve files from the server. GET response includes file (mime application/octet-stream). Your network firewall should allow such connections.

3 How to use the plugin

3.1 Nozzle duct

1. Start "Select nozzle duct" command from ribbon button or use the AutoCAD command line command *REPUSND*.



Button starts the Repus Calculation Tool inside AutoCAD.

2. Select type of the nozzle duct.


Repus MagiCAD Plugin 2019.8.1

— □ ×



Repus configurator for MagiCAD

Choose duct type



- After the type is selected, the user configures the nozzle duct and clicks "Calculate" button.



Configure nozzle duct

Length A (m)

Connection diameter D (mm)

Spreading

End velocity jet (m/s)

Mounting height floor -> duct (m)

Delta temp (° C)

Max noise level
 Units

Air flow
 Units



- When the nozzle duct is successfully calculated, "Finish" button can be clicked and insert operation starts.

- Then the plugin asks user code from the user.


Repus MagiCAD Plugin 2019.8.1 ×

Click Import to insert product from Repus Calculator.
Click Cancel to close.

User code


Please write "TD" number, for example TD123.

6. Show the position for the device and select the MagiCAD system.




Note! You can add more similar devices. After you have added all, please press ESC.

7. Continue with MagiCAD e.g. draw the duct and connect it to the device.




3.2 Displacement diffuser

1. Start "Select displacement diffuser" command from ribbon button or use the AutoCAD command line command *REPUSDD*.



Button starts the Repus Calculation Tool inside AutoCAD.

2. Select type of the displacement diffuser.



- After the type is selected, the user configures the diffuser and clicks "Calculate" button.



Configure diffuser

Product code
CP

Dimension A (mm)
750

Dimension B (mm)
1650

Dimension C (mm)
260

Connection type
Circular


Diameter (mm)
80

Connection placement
Top

Quantity
1

Air flow
80

Units
l/s



Buttons: Cancel, **Calculate**, Finish

- When the diffuser is successfully calculated, "Finish" button can be clicked and insert operation starts.

Buttons: Cancel, Calculate, **Finish**

- Then the plugin asks user code from the user.


Repus MagiCAD Plugin 2019.8.1

Click Import to insert product from Repus Calculator.
Click Cancel to close.

User code

Please write "TD" number, for example TD123.

6. Show the position for the device and select the MagiCAD system.



MagiCAD V&P - Install product

Fill data from: 

System: 

Status: 

Description:

Height level in current floor coordinate system

Top level: mm 

Connection level: mm 

Installation level: mm 

Bottom level: mm 

☐ Show this dialog between installation

User variables

Property	Value
UserVar 1	
UserVar 2	
UserVar 3	
UserVar 4	

Object Id

☐ Override

Coordinate system

☒ Use current floor coordinate system

☐ Use absolute coordinate system



Note! You can add more similar devices. After you have added all, please press ESC.

7. Continue with MagiCAD e.g. draw the duct and connect it to the device.

